

Model
WK5
Maximum pipe diameter

159 mm

Direct Fired Water Heaters . We recommend maximum heat rating for different sized units and this also varies according to whether they are gas fired, oil fired or heated electrically.

Direct fired gas / oil

1125 kW

Electrical boiler

150 kW

Flow Rate . Flow rate is immaterial as far as Water-King is concerned. The greater the flow, the more effective the units tend to be.

Product Data

○ Aerial Length	9.0 m
○ Aerial Number	6
○ Minimum aerial turns	15 Turns
○ Frequency range	1 . 10 kHz
○ Peak to peak output voltage	82 V
○ Power supply required	230 V or 110 V
○ Input current	0.1 A
○ Power consumption	3 W
○ Transformer output	Integral to unit
○ Power cable length	1.5 m
○ Dimensions	280mm x 210mm x 140mm
○ Weight	3.25 kg
○ Ambient temperature	0 . 70 °C
○ Humidity non-condensing	80 %
○ Self-diagnostic guard chip	Yes
○ BMS output	Yes
○ IP Rating	65
○ Fuse	20 mm 1 Amp.T. (time delay)

Self-Diagnostic “Guard Chip” . Every computer system is prone to malfunction, especially if there is a sudden variation in the power supply, which can jam the program. Most systems have to reset by manual re-booting. Water-King units overcome this problem by an additional %Guard Chip+program, which monitors the performance of the main program and resets the system automatically if it detects a variation or system failure. There is no need for manual resetting after power outage.

Maintenance . Once installed, the WK5 requires no maintenance.

Lifecycle costs . Running costs are less than £5.00 per annum. The design life is 25 years with a 5-year manufacturer's warranty.

UPC . 5031476000053